

Dyna Wide Glide® - FXWG (2004 to Present)

Edge Brackets Quick Release Detachable saddlebag system

Edge Brackets system allows you put on or take off your saddlebags in roughly two seconds!

The Edge Brackets system is easy to install and once installed no tools are needed to remove your saddlebags. Edge Brackets are installed by removing the two bolts from your fenders and replacing the two OEM bolts with the Ghost Bracket bolts and hardware which are called "keepers". The Edge Brackets are then bolted on to your saddlebag and simply slide right on to the keepers.

Now with the latest Generation III (G3) Edge Brackets you will have the most versatile saddlebag system ever developed. Made from solid 10 gauge steel, the brackets are specialty pretreated and then black powder coated for durability and good looks. All the hardware provided is stainless steel that is polished to a show room finish. The Generation III Edge Brackets are completely adjustable in every direction allowing you to place your bags on the bike exactly where you need them not only getting you the exact look you desire, but also helping to avoid many undesirable turn signal relocation requirements. Simply slide the bracket on the stainless steel keepers, turn your locking key and the brackets and your expensive saddlebags are safe, securely locked onto your bike. Why settle for just one set of saddlebags? With Edge Brackets your saddlebags are interchangeable allowing for multiple sets of saddlebags to be used.

Edge Brackets G3 Model 106

Fits fender bolt width 4 1/2" - 10 3/8"

Large Image

Carry EEZ carrying handle for Edge Brackets

A voluble accessory for every Edge Brackets owner. This carrying handle sports a convenient leather strap and specially designed polished stainless steel slotted keepers that slide into the Edge Brackets mounting slots. The Carry EEZ allows you to conveniently carry both your saddlebags when you want to remove them from your motorcycle. No fumbling when trying to carry both your saddlebags at once, just slip both your bags onto the keepers and you now have one hand free to open doors, search your pockets, or wave at friends. Be the envy of your riding group with a Quick Release Detachable setup and the Carry EEZ Leather carrying handle. \$36.95 Buy Now

Large Image 1

Large Image 2 Edge Brackets

Part Number GB-HD-DNA-106 (For Dynas with standard hardmount backrest or no backrest installed) Fitment Details

- Recommended for small, medium, large or slanted saddlebags which at least 15" in length at mounting point.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on the two existing mounting bolts of the fender rail (In some cases the turn signal may occupy one of the mounting points).

- For use on models where standard hardmount backrest, or no backrest is installed.

- No turn signal relocation required. Price \$154.95 Buy Now

Part Number GB-HD-DNA4DBK-106 (For Dynas with Harley Davidson detachable backrest installed) Fitment Details

- Recommended for small, medium, large or slanted saddlebags which at least 15" in length at mounting point.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on the two existing mounting bolts of the fender rail (In some cases the turn signal may occupy one of the mounting points).

- For use on models where Harley Davidson detachable backrest is installed.

- No turn signal relocation required. Price \$154.95 Buy Now BACKREST KIT Edge Brackets backrest kits allow for integration of your Edge Brackets and the new backrest (sissy bar) and are used when the backrest is purchased after Edge Brackets have already been installed on the bike.

Part Number GB-BK-HD-DNA4-DB Fitment Details

- For use with HD detachable backrests Price \$14.95 Buy Now ACCESSORY KITS

Part Number GB1-SK-OEM-BAG Fitment Details

- Specialty bolt and spacer kit used for mounting molded aftermarket and/or OEM saddlebags where the back of the saddlebag is not flat. Price \$36.95 Buy Now

PRODUCT ILLUSTRATION