

Vegas Low (2008 - Present)

Edge Brackets Quick Release Detachable saddlebag system

Edge Brackets system allows you put on or take off your saddlebags in roughly two seconds!

The Edge Brackets system is easy to install and once installed no tools are needed to remove your saddlebags. Edge Brackets are installed by removing the two bolts from your fenders and replacing the two OEM bolts with the Ghost Bracket bolts and hardware which are called "keepers". The Edge Brackets are then bolted on to your saddlebag and simply slide right on to the keepers.

Now with the latest Generation III (G3) Edge Brackets you will have the most versatile saddlebag system ever developed. Made from solid 10 gauge steel, the brackets are specialty pretreated and then black powder coated for durability and good looks. All the hardware provided is stainless steel that is polished to a show room finish. The Generation III Edge Brackets are completely adjustable in every direction allowing you to place your bags on the bike exactly where you need them not only getting you the exact look you desire, but also helping to avoid many undesirable turn signal relocation requirements. Simply slide the bracket on the stainless steel keepers, turn your locking key and the brackets and your expensive saddlebags are safe, securely locked onto your bike. Why settle for just one set of saddlebags? With Edge Brackets your saddlebags are interchangeable allowing for multiple sets of saddlebags to be used.

Edge Brackets G3 Model 105

Fits fender bolt width 4 1/2" - 7 5/8"

Large ImageEdge Brackets G3 Model 106

Fits fender bolt width 4 1/2" - 10 3/8"

Large Image{tab=Fitments}

Please select the fitment below that best describes your motorcycle configuration.

{slide=Victory Vegas Low models with NO BACKREST installed} Part Number GB-P-VV-105 (For smaller to medium size bags on bikes with no backrest installed)Fitment Details

- Recommended for small, medium or slanted saddlebags up to 22" in length.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on two existing mounting bolts of the fender rail.

- For use on models where no backrest is installed.
- No turn signal relocation required.Coming October 2008Price\$154.95Buy Now

Part Number GB-P-VV-106 (For medium to large size bags on bikes with no backrest installed)Fitment Details

- Recommended for medium or large saddlebags over 20" in length.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on two existing mounting bolts of the fender rail.

- For use on models where no backrest is installed.

- No turn signal relocation required.Coming October 2008Price\$154.95Buy Now {/slide}

{slide=Victory Vegas Low models with AFTERMARKET BACKREST installed on the fender rails} Part Number GB-P-VVBK-105 (For smaller to medium size bags on bikes with standard OEM or aftermarket backrest installed)Fitment Details

- Recommended for small, medium or slanted saddlebags up to 22" in length.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on two existing mounting bolts of the fender rail.

- For use on models where standard OEM or aftermarket backrest installed on fender rails. Not applicable for backrests attached to the seat.

- No turn signal relocation required. Coming October 2008 Price \$154.95 Buy Now
Part Number GB-P-VVBK-106 (For medium to large size bags on bikes with standard OEM or aftermarket backrest installed) Fitment Details
- Recommended for medium or large saddlebags over 20" in length.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on two existing mounting bolts of the fender rail.
- For use on models where standard OEM or aftermarket backrest installed on fender rails. Not applicable for backrests attached to the seat.

- No turn signal relocation required. Coming October 2008 Price \$154.95 Buy Now {/slide}
{slide=Victory Vegas Low models with VICTORY OEM LUGGAGE RACK installed on fender rails} Part Number GB-P-VVLR-105 (For smaller to medium size bags on bikes with standard OEM Luggage Rack is installed) Fitment Details
- Recommended for small, medium or slanted saddlebags up to 22" in length.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on two existing mounting bolts of the fender rail.
- For use on models where standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.

- No turn signal relocation required. Coming October 2008 Price \$154.95 Buy Now
Part Number GB-P-VVLR-106 (For medium to large size bags on bikes with standard OEM Luggage Rack is installed) Fitment Details
- Recommended for medium or large saddlebags over 20" in length.
- For use with flat surface mounting saddlebags only (most aftermarket hardmount saddlebags where the rear of the saddlebag is flat)
- For molded aftermarket or OEM saddlebags such as Harley Heritage saddlebags please also purchase the GB1-SK-OEM-BAG kit.
- Installation is done on two existing mounting bolts of the fender rail.
- For use on models where standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.

- No turn signal relocation required. Coming October 2008 Price \$154.95 Buy Now {/slide}
{tab=Backrest Kits}
- Edge Brackets backrest kits allow for integration of your Edge Brackets and the new backrest (sissy bar) and are used when the backrest is purchased after Edge Brackets have already been installed on the bike.

Part Number GB-BK-P-VVKP Fitment Details

- For use with standard OEM or aftermarket backrest installed on fender rails. Not applicable for backrests attached to the seat. Price \$19.95 Buy Now

{tab=Accessories} Part Number GB-CE-101 Fitment Details

- A valuable accessory for every Edge Brackets owner. This carrying handle sports a convenient leather strap and specially designed polished stainless steel slotted keepers that slide into the Edge Brackets mounting slots. The Carry EEZ allows you to conveniently carry both your saddlebags when you want to remove them from your motorcycle. No fumbling when trying to carry both your saddlebags at once, just slip both your bags onto the keepers and you now have one hand free to open doors, search your pockets, or wave at friends. Be the envy of your riding group with a Quick Release Detachable setup and the Carry EEZ Leather carrying handle.

Large Image 1

Large Image 2 Price \$36.95 Buy Now

Part Number GB1-SK-OEM-BAG Fitment Details

- Specialty bolt and spacer kit used for mounting molded aftermarket and/or OEM saddlebags where the back of the saddlebag is not flat. Price \$36.95 Buy Now

{tab=Images}

Å {/tabs}