

EDGE™ Brackets On Harley Davidson Heritage Softail with OEM Saddlebags

EDGE™ Brackets are really simple to install onto your motorcycle, even with molded OEM saddlebags like the Heritage bags from Harley Davidson. This image demo will give you a great idea of how the brackets get attached to an uneven surface on saddlebags like these. In this case, we used a 1998 Harley Davidson Heritage Softail with OEM Heritage Saddlebags and a set of our GB-HD-UKHBK-106 EDGE™ Brackets.

Step 1 Step 2 Step 3 Step 4 Step 5 Step 6 Step 7 Step 8 Step 9 Step 10 Step 11 Step 12 Step 13 Step 14